


DIAGRAM OF ROOF WINDOW ROLLER-BLIND MEASUREMENT TAKING



When placing your order for roof window roller-blinds, it is necessary for you to specify **the blind's total width**, i.e. the width between the inner edges of the window frame (W); however, in the case of VELUX type windows, which have their original blind fixtures, it is necessary for you to specify in your order form the width measured between these fixtures.

PLEASE FOLLOW THE WAY OF MEASUREMENT TAKING AND PRECISELY MEASURE THE WINDOWS.